



MICRO ROCKET

BATTERY POWERED SMOKE MACHINE



1
Connect charger clip to battery and charge for 8 hrs (initial charge only). Thereafter a full charge should take 2-3 hours. A fully charged battery will give approx 10 mins smoke production.



2
Fill the Micro Rocket with the appropriate Smoke Fluid. The fluid level can be monitored on the sight glass. Do not overfill. Replace the Micro Rocket filler cap tightly



3
Align battery so the electrical contacts are on the Right Hand Side of the centreline of the Micro Rocket.



4
Lift the battery retaining clip, and slide the battery into the Micro Rocket fully, so that the electrical contacts become engaged.



5
The view when battery is fully engaged



SMOKE ON

To produce smoke press the red button on the handle. A green LED will start to flash, and smoke will be produced in 1-2 seconds.

SMOKE OFF

To stop the smoke, press the red button again. Smoke production will stop in 1-2 seconds. The green LED will continue to flash for about 10 seconds.

Note: LED flashing red means battery needs charging.

Please refer to full instructions

Pea Soup Ltd
www.smokemachines.net



SHUT DOWN

- Remove battery from the Micro Rocket
- Empty the fluid reservoir when the unit is no longer required